

# Automatic Transfer Switches



## Safety Cautions

- Please read this user manual carefully for safe use of this switchgear before using it.
- The switchgear described in this manual has limitations in use, conditions, locations, and etc., and require regular inspections.  
Please contact your local reseller or us for appropriate use of this switchgear.
- Do not disassemble or repair this switchgear for maintenance or repair.  
Please contact authorized and certified individuals for maintenance or repair.
- For your own safety, it is recommended that you use a specialist in electrical engineering, electrical wiring, etc.

# VITZRO EM

I N S T R U C T I O N M A N U A L

# Automatic Transfer Switches

Instruction Manual



## Safety Precautions for Switchgear

### Safety Precautions

Thank you for purchasing VITZRO EM switchgear. These safety precautions provide important descriptions related to safety. Before starting any types of operations with the switchgear, please read these safety precautions, the user manual, and other related documentation for appropriate use. Use this switchgear only after reading and understanding all of the safety information and precautions for it. In this user manual, the safety precautions are classified into three categories based on the severity: [Danger], [Warning], and [Caution].

 **DANGER** A critical situation which can cause death or serious injury when the switchgear is handled improperly.

 **WARNING** A serious situation which may cause death or serious injury when the switchgear is handled improperly.

 **CAUTION** A potentially serious situation which may cause a moderate or slight injury when the switchgear is handled improperly.

### ◆ Cautions when transporting

 **DANGER**

- Do not go under the switchgear when lifting it with lifters or with chain-blocks. As switchgear is heavy, it may cause injuries or even death when dropped.

### ◆ Cautions for Installation (Connection and Mount)

 **DANGER**

- Only qualified individuals (electrical engineers or electrical engineering certified technicians) should perform installation.
- Before starting installation, open all of the breakers to block all power supplies. Otherwise, electric shock may occur.
- Connect terminal bolts with the standard torque. Otherwise, a fire may occur.
- Firmly connect and fix the switchgear vertically on a flat surface.
- Do not install the switchgear in an environment where high temperature, high humidity, corrosive gas, dust, vibration, or shock exists. Fire, non-trip, or malfunction may occur.
- Prevent dust, concrete dust or metal shavings from getting into the switchgear. Fire, non-trip, or malfunction may occur.
- For the 4-pole switch, connect the neutral line of the 3-phase 4-line to the phase N pole. Overcurrent may cause non-trip or fire.

### ◆ Cautions for Operation

 **DANGER**

- Do not touch the main circuit, control circuits, or the terminal section being energized. Otherwise, an electric shock may occur.

 **CAUTION**

- When a breaker is open (tripped) automatically, remove the cause and provide the power. Otherwise, a fire may occur.

### ◆ Cautions for Repair, Inspection, and Part Replacement

 **CAUTION**

- Only qualified individuals should perform repair, inspection, and part replacement.
- Before starting any work, turn off the switchgear, and check whether all of the main circuit and the control circuits are de-energized. Otherwise, an electric shock may occur.
- Before inspecting the inside of the switchgear open the breaker and ensure that Power A and the Power B are open. Otherwise, fingers or tools may be caught and injured in the equipment.
- Check and tighten the terminal bolts with the standard torque in a regular basis. Loose bolts may lead to a fire.

## Table of Contents

<b>1. Handling</b> .....	<b>04</b>
1-1. Storage .....	<b>04</b>
1-2. Transport .....	<b>04</b>
<b>2. Ratings</b> .....	<b>05</b>
2-1. W Type .....	<b>05</b>
2-2. WN Type .....	<b>06</b>
2-3. CTTS Type .....	<b>08</b>
<b>3. Installation</b> .....	<b>10</b>
3-1. Installation .....	<b>11</b>
3-2. Panel Dimensions .....	<b>11</b>
<b>4. Operation</b> .....	<b>16</b>
4-1. Manual Operation .....	<b>16</b>
4-2. Automatic Operation .....	<b>18</b>
4-3. Circuit Diagram (CTTS) .....	<b>21</b>
<b>5. External Dimensions</b> .....	<b>23</b>
<b>6. Inspection and Repair</b> .....	<b>38</b>
<b>7. Regular Inspection</b> .....	<b>39</b>

# 1. Handling

For storage, transport, and installation of the switchgear, read this manual carefully and understand all of the safety information and precautions before using the equipment.

## 1-1 Storage

The switchgear must be installed immediately after delivered. However, if it is impossible for any reason, please follow the instructions described below.

1. High temperature and high humidity degrade the performance of the switchgear. Please store the switchgear in a dry place.  
(Accidents may occur when any foreign materials get into the energized sections.)
2. Do not store the switchgear outdoors or in the place where dust or harmful gas exist.  
Otherwise, corrosion of the switchgear may occur.
3. Store the switchgear on a flat surface without touching the floor directly.
4. The switchgear must be "OPEN" and the string must be "DISCHARGED" while being stored.

## 1-2 Transport

Please follow the instructions described below when transporting the switchgear.



**DANGER**

- Do not go under the switchgear when lifting the switchgear with lifters or with chain-blocks.
- The switchgear is heavy which may cause injuries or death when dropping.

1. Make sure that the type "WN" switchgear is in the "OPEN" state while transporting it.
2. Move the switchgear slowly to avoid any shock to the switch.

## 2. Ratings

### 2-1. W Type

Types			61W		62W		64W		
Rated Current (In)	A		100		200		400		
Rated Operational Voltage (Ue)	V		AC600		AC600		AC600		
Rated Insulation Voltage (Ui)	V		AC800		AC800		AC800		
Rated Impulse Withstand Voltage (Uimp)	kV		8		8		8		
Number of Poles	P		3, 4		3, 4		2, 3, 4		
Number of Throws	T		Double Throw		Double Throw		Double Throw		
Connection Type			Front		Front		Front, Back		
Performance									
Rated Short Time Current (1sec) Icw	kA		5		10		12		
Rated Short-circuit Closing Current Icm	kA		5		10		12		
With breakers (SPCD)	kA		14		25		35		
With fuses	kA		200		200		200		
Switching Capability <sup>Note 1)</sup>		Class	AC-33B		AC-33B		AC-33B		
Life Time	Electrical	Number	5,000		5,000		5,000		
	Mechanical	Number	10,000		10,000		10,000		
Switchover Sequence			A ↔ B		A ↔ B		A ↔ B		
Run Time	Opening	msec	≤30		≤30		≤60		
	Switching	msec	≤60		≤60		≤200		
	Off	sec	-		-		-		
Operating Voltage and Current (rms)			3P	4P	3P	4P	2P	3P	4P
Switching	AC/DC 110V	A	-	-	-	-	7	7	10
	AC 220V	A	8	8	8	8	3.5	3.5	5
External Dimensions and Weight									
Weight	Front	kg	2.5	3	3.5	4	7.5	9	10.5
	Back	kg	-	-	-	-	6	8	10

Note 1) Switching Capacity : Class AC-33B : Overload switching performance (Closing  $10 \times I_e$ , Breaking  $10 \times I_e$ ,  $\cos\theta = 0.35$ ),  
Rated load switching performance (Closing  $1 \times I_e$ , Breaking  $1 \times I_e$ ,  $\cos\theta = 0.8$ )



W Type(100~200A)



W Type(400A) / WN Type(~600A)



WN Type(800~3000A)

## 2-2. WN Type

Types			61WN			62WN			64WN			66WN		68WN		
Rated Current (In)	A		100			200			400			600		800		
Rated Operational Voltage (Ue)	V		AC600			AC600			AC600			AC600		AC600		
Rated Insulation Voltage (Ui)	V		AC800			AC800			AC800			AC800		AC800		
Rated Impulse Withstand Voltage (Uimp)	kV		8			8			8			8		8		
Number of Poles	P		2, 3, 4			2, 3, 4			2, 3, 4			3, 4		3, 4		
Number of Throws	T		Double Throw													
Connection Type			Front, Back													
Performance																
Rated Short Time Current (1sec) I <sub>cw</sub>	kA		5			10			12			15		22		
Rated Short-circuit Closing Current I <sub>cm</sub>	kA		5			10			12			15		22		
With breakers (SPCD)	kA		14			25			35			42		50		
With fuses	kA		200			200			200			200		200		
Switching Capacity <sup>Note 1)</sup>	Class		AC-33B			AC-33B			AC-33B			AC-33B		AC-33B		
Life Time	Electrical	Number	5,000			5,000			5,000			5,000		5,000		
	Mechanical	Number	10,000			10,000			10,000			10,000		10,000		
Switchover Sequence			A ↔ B, A ↔ Neutral(off) ↔ B													
Run Time	Closing	msec	≤60			≤60			≤60			≤100		≤100		
	Trip	msec	≤20			≤20			≤20			≤30		≤30		
Operating Voltage and Current (rms)			2P	3P	4P	2P	3P	4P	2P	3P	4P	3P	4P	3P	4P	
Closing	AC/DC 110V	A	7	7	7	7	7	7	8	8	8	8	10	10	10	
	AC 220V	A	3.5	3.5	3.5	3.5	3.5	3.5	4	4	4	4	5	5	5	
Trip <sup>Note 2)</sup>	AC/DC 110V	A	3			3			3			4		4		
	AC 220V	A	1.5			1.5			1.5			2		2		
External Dimensions and Weight																
Weight	Front	kg	4.5	6	8	4.5	6	8	7.5	9	10.5	15	18	20	24	
	Back	kg	4.5	6	8	4.5	6	8	6	8	10	14	17	19	23	

Note 1) Switching Capacity : Class AC-33B : Overload switching performance (Closing  $10 \times I_e$ , Breaking  $10 \times I_e$ ,  $\cos\theta = 0.35$ ),  
Rated load switching performance (Closing  $1 \times I_e$ , Breaking  $1 \times I_e$ ,  $\cos\theta = 0.8$ )



Note 2) Trip : The phenomenon in which the circuit at the Power A or the Power B is open to the Neutral position.

Types			610WN	612WN	616WN	620WN	625WN	630WN						
Rated Current (In)	A		1000	1200	1600	2000	2500	3000						
Rated Operational Voltage (Ue)	V		AC600	AC600	AC600	AC600	AC600	AC600						
Rated Insulation Voltage (Ui)	V		AC800	AC800	AC800	AC800	AC800	AC800						
Rated Impulse Withstand Voltage (Uimp)	kV		8	8	8	8	8	8						
Number of Poles	P		3, 4	3, 4	3, 4	3, 4	3, 4	3, 4						
Number of Throws	T		Double Throw											
Connection Type			Front, Back				Back							
Performance														
Rated Short Time Current (1sec) Icw	kA		22	25	32	40	50	50						
Rated Short-circuit Closing Current Icm	kA		22	25	32	40	50	50						
With breakers (SPCD)	kA		50	65	65	85	85	85						
With fuses	kA		200	200	200	200	200	200						
Switching Capability <sup>Note 1)</sup>	Class		AC-33B	AC-33B	AC-33B	AC-33B	AC-33B	AC-33B						
Life Time	Electrical	Number	5,000	5,000	5,000	3,000	3,000	3,000						
	Mechanical	Number	10,000	10,000	10,000	5,000	5,000	5,000						
Switchover Sequence														
Run Time	Closing	msec	≤ 100	≤ 150	≤ 150	≤ 180	≤ 180	≤ 180						
	Trip	msec	≤ 30	≤ 30	≤ 30	≤ 35	≤ 35	≤ 35						
Operating Voltage and Current (rms)			3P	4P	3P	4P	3P	4P	3P	4P	3P	4P		
Closing	AC/DC 110V	A	10	10	8	10	8	10	13	16	-	-	-	-
	AC 220V	A	5	5	4	5	4	5	6.5	8	12	15	12	15
Trip <sup>Note 2)</sup>	AC/DC 110V	A	4		4		4		4		-		-	
	AC 220V	A	2		2		2		2		2		2	
External Dimensions and Weight														
Weight	Front	kg	21	25	52.5	63.5	58	69	-	-	-	-	-	-
	Back	kg	20	24	50	60	55	65	65	85	92.5	119	92.5	119

Note 1) Switching Capacity : Class AC-33B : Overload switching performance (Closing  $10 \times I_e$ , Breaking  $10 \times I_e$ ,  $\text{Cos}\theta = 0.35$ ),  
Rated load switching performance (Closing  $1 \times I_e$ , Breaking  $1 \times I_e$ ,  $\text{Cos}\theta = 0.8$ )

Note 2) Trip : The phenomenon in which the circuit at the Power A or the Power B is open to the Neutral position.



## 2-3. CTTS Type

Types		61CT			62CT			64CT			66CT		
Rated Current (In)	A	100			200			400			600		
Rated Operational Voltage (Ue)	V	AC600			AC600			AC600			AC600		
Rated Insulation Voltage (Ui)	V	AC800			AC800			AC800			AC800		
Rated Impulse Withstand Voltage (Uimp)	kV	8			8			8			8		
Number of Poles	P	2, 3, 4			2, 3, 4			2, 3, 4			3, 4		
Number of Throws	T	Double Throw			Double Throw			Double Throw			Double Throw		
Connection Type	Front	●			●			●			●		
	Back	-			-			●			●		
Performance													
Rated Short Time Current (1sec) Icw	kA	5			10			12			15		
Rated Short-circuit Closing Current Icm	kA	5			10			12			15		
With breakers (SPCD)	kA	14			25			35			50		
With fuses	kA	200			200			200			200		
Switching Capability <sup>Note 1)</sup>	Class	AC-33B			AC-33B			AC-33B			AC-33B		
Life Time	Electrical	Number	5,000			5,000			5,000			5,000	
	Mechanical	Number	10,000			10,000			10,000			10,000	
Switchover Sequence		A↔Overlapping↔B, A↔B, A↔Neutral(off)↔B											
Conditions of Uninterruptible Switchover		Phase Difference: within the electrical angle of 10°. Frequency Difference: within 0.2 Hz. Voltage: within 5% of the voltage difference with the all-electric power source, instantaneous coupled time: within 0.05 sec.											
Run Time	Closing	msec	≤60			≤60			≤100			≤150	
	Trip	msec	≤20			≤20			≤30			≤30	
Operating Voltage and Current (rms)			2P	3P	4P	2P	3P	4P	2P	3P	4P	3P	4P
Closing	AC/DC 110V	A	5	5	7	7	7	7	7	7	9	7	8
	AC 220V	A	2.5	2.5	3.5	3.5	3.5	3.5	3.5	3.5	4.5	3.5	4
Trip <sup>Note 2)</sup>	AC/DC 110V	A	3			3			4			4	
	AC 220V	A	1.5			1.5			2			2	
External Dimensions and Weight													
Front Dimensions		H	268	268	268	283	283	283	307	307	307	545	545
		W	210.8	240.8	270.8	240.8	285.8	330.8	292.5	352.5	412.5	465	530
		D	111	111	111	111	111	111	132	132	132	219.4	219.4
Back Dimensions		H	-	-	-	-	-	-	-	-	-	478	478
		W	-	-	-	-	-	-	-	-	-	465	530
		D	-	-	-	-	-	-	-	-	-	254.4	254.4
Weight	Front	kg	6.5	8	10	8	10	12	14	17	21	53	61
	Back	kg	-	-	-	-	-	-	-	-	-	-	-

Note 1) Switching Capacity : Class AC-33B : Overload switching performance (Closing 10×Ie, Breaking 10×Ie, Cosθ = 0.35), Rated load switching performance (Closing 1×Ie, Breaking 1×Ie, Cosθ = 0.8)

Note 2) Trip : The phenomenon in which the circuit at the Power A or the Power B is open to the Neutral position.

Note 3) 416CT/425CT have adequate test reports.

Types		610CT	616CT   416CT <sup>Note 3)</sup>		620CT	425CT <sup>Note 3)</sup>		630CT				
Rated Current (In)	A	800, 1000	1200, 1600		2000	2,500		2500, 3000				
Rated Operational Voltage (Ue)	V	AC600	AC600   AC415V		AC600	AC415		AC600				
Rated Insulation Voltage (Ui)	V	AC800	AC800   AC600V		AC800	AC600		AC800				
Rated Impulse Withstand Voltage (Uimp)	kV	8	8   6		8	6		8				
Number of Poles	P	3, 4	3, 4		3, 4	3, 4		3, 4				
Number of Throws	T	Double Throw	Double Throw		Double Throw	Double Throw		Double Throw				
Connection Type	Front	●	●		-	-		-				
	Back	-	●		●	●		●				
Performance												
Rated Short Time Current (1sec) I <sub>cw</sub>	kA	25	32		40	50		50				
Rated Short-circuit Closing Current I <sub>cm</sub>	kA	25	32		40	50		50				
With breakers (SPCD)	kA	50	65		85	85		85				
With fuses	kA	200	200		200	200		200				
Switching Capability <sup>Note 1)</sup>	Class	AC-33B	AC-33B		AC-33B	AC-33B		AC-33B				
Life Time	Electrical	Number	5,000		3,000	3,000		3,000				
	Mechanical	Number	10,000		5,000	5,000						
Switchover Sequence	A↔Overlapping↔B, A↔B, A↔Neutral(off)↔B											
Conditions of Uninterruptible Switchover	Phase Difference: within the electrical angle of 10°. Frequency Difference: within 0.2 Hz. Voltage: within 5% of the voltage difference with the all-electric power source, instantaneous coupled time: within 0.05 sec.											
Run Time	Closing	msec	≤150	≤150		≤250		≤250		≤250		
	Trip	msec	≤30	≤60		≤80		≤80		≤80		
Operating Voltage and Current (rms)			3P	4P	3P	4P	3P	4P	3P	4P		
Closing	AC/DC 110V	A	8	10	10/16	13/16	13	16	-	-	16	18
	AC 220V	A	4	5	5/8	6.5/8	6.5	8	12	12	8	9
Trip <sup>Note 2)</sup>	AC/DC 110V	A	4		4/4		4		-		4	
	AC 220V	A	2		2/4		2		4		2	
External Dimensions and Weight												
Front Dimensions		H	607	607	644	644	-	-	-	-	-	-
		W	510	590	570	670	-	-	-	-	-	-
		D	219.4	219.4	219.4	219.4	-	-	-	-	-	-
Back Dimensions		H	478	478	478	478	580	580	580	580	580	580
		W	510	590	570	670	685	820	835	1020	835	1020
		D	299.4	299.4	299.4	299.4	335	335	370	370	370	370
Weight	Front	kg	66	76	72	84	-	-	-	-	-	-
	Back	kg	-	-	72	84	130	150	165	205	165	205

Note 1) Switching Capacity : Class AC-33B : Overload switching performance (Closing 10×I<sub>e</sub>, Breaking 10×I<sub>e</sub>, Cosθ = 0.35), Rated load switching performance (Closing 1×I<sub>e</sub>, Breaking 1×I<sub>e</sub>, Cosθ = 0.8)

Note 2) Trip : The phenomenon in which the circuit at the Power A or the Power B is open to the Neutral position.

Note 3) 416CT/425CT have adequate test reports.

### 3. Installation

Please read and follow the instructions below before installation.

**! DANGER**


- Block all power supplies including the main circuit and the control circuits before installation. Otherwise, fire, electric shock, or a severe accident may occur.

**! CAUTION**

- Only qualified individuals (electrical engineers or electrical engineering certified technicians) should perform the installation. Otherwise, the switchgear may malfunction.
- Do not install the switchgear in a place where high temperature, high humidity, or harmful gas exists. Otherwise, the switchgear may malfunction.
- Maintain a sufficient insulation distance from the ARC CHUTE. Otherwise, the switch performance may be lowered.
- Firmly connect and fix the switchgear vertically on the flat surface with the standard torque. Otherwise, it may fall.

**! CAUTION**

- If a dropper circuit is included in the DC control power, the ATS control power should be connected to the input of the dropper circuit, not to the output.




**! CAUTION**

- Use the control powers and lines with sufficient capacities. In particular, be careful of the battery capacity for DC control.

**! CAUTION**

- For the DC control specifications for 61-630WN, connect A1 and B1 to the +(P), and A2 and B2 to the -(N).





### 3-1. Installation



**CAUTION**


• Do not pull the lines forcibly which connect the switch bus and the panel bus. Otherwise, it may lead to a fire or failure of operation properties.

1. The ATS is designed to be installed in a specific direction. Changing this installation direction changes the properties of ATS. Be careful of the direction while installing the ATS.
2. If it is not possible to install the switchgear in a correct way due to the wiring or layout of the peripheral equipment, please contact us.
3. The switchgear should be installed in the direction from which you can see the switch nameplate in front of the switchgear, as well as the switchgear should be parallel to the vertical surface of the panel.




### 3-2. Panel Dimensions

#### 1) Type W 100A-200A Dimensions




#### 2) Type W 400A Dimensions



TYPE	100-200A		400A	
	FRONT	FRONT	FRONT	BACK
A	91	152	-	-
B	2P	-	141	141
	3P	148	192	192
	4P	148	243	243
C	150	152	152	
D	2P	-	-	120
	3P	-	-	170
	4P	-	-	220
E	-	-	9.5	
F	-	-	155	
G	4	3	3	
H	9	9	9	


### 3-2. Panel Dimensions

#### 3) Type WN 100A-1000A Dimensions



TYPE	100~200A		400A		600A		800A		1000A		
	FRONT	BACK	FRONT	BACK	FRONT	BACK	FRONT	BACK	FRONT	BACK	
A	152	152	152	152	200	200	200	200	200	200	
B	2P	111	111	141	141	-	-	-	-	-	-
	3P	147	147	192	192	224	224	284	284	284	284
	4P	183	183	243	243	284	284	364	364	364	364
C	2P	-	88	-	118	-	-	-	-	-	-
	3P	-	124	-	169	-	200	-	250	-	250
	4P	-	160	-	220	-	260	-	330	-	330
D	-	9.5	-	9.5	-	9	-	9	-	9	
E	-	172	-	155	-	215	-	240	-	240	
F	10	10	10	10	10	10	10	10	10	10	
G	7	7	7	7	10	10	10	10	10	10	


#### 4) Type WN 1200A-3000A Dimensions



TYPE	1200A		1600A		2000A	3000A
	FRONT	BACK	FRONT	BACK	BACK	BACK
A	349.5	349.5	349.5	349.5	349.5	349.5
B	2P	-	-	-	-	-
	3P	334	334	334	409	482
	4P	417	417	417	517	617
C	2P	-	-	-	-	-
	3P	-	279	-	279	354
	4P	-	362	-	362	462
D	-	18.5	-	18.5	18.5	18.5
E	-	390	-	390	390	390
F	14	14	14	14	14	14
G	-	-	-	-	-	-


### 3-2. Panel Dimensions

#### 5) 61-64CT Front Connection




Type	100A	200A	400A	
A	2P	199.8	229.8	278.5
	3P	229.8	274.8	338.5
	4P	259.8	319.8	398.5
B	152		200	
C	76		100	
R	M5		M8	

#### 6) 66-616CT Front Connection




Type	600A	800A	1000A	1200A	1600A
A	3P	435	480	540	
	4P	500	560	640	

#### 7) 66-616CT Back Connection




Type	600A	800A	1000A	1200A	1600A
A	3P	435	480	540	
	4P	500	560	640	
B	3P	375	420	480	
	4P	440	500	580	

## 8) 620-630CT Back Connection



**CTTS 2000A-3000A(3P)**




**CTTS 3000A(4P)**

Type		2000A	3000A
A	3P	645	795
	4P	780	980
B	3P	420	570
	4P	555	755

## 4. Operation

Please read and follow the instructions below while operating the switchgear.

 <b>CAUTION</b>	<ul style="list-style-type: none"> <li>Do not touch or get near to the energized main circuit or control circuits. Otherwise, electric shock may occur.</li> </ul>
 <b>CAUTION</b>	<ul style="list-style-type: none"> <li>Closing and rack-out operation are completed within 0.3 seconds. However, for safe and correct operation, set the sequence to issue the control command for more than 0.5 seconds.</li> </ul> 
 <b>CAUTION</b>	<ul style="list-style-type: none"> <li>Do not issue both the closing command and the trip command; when both the closing command and the trip command are issued to the same power simultaneously, the switch status is changed to the closing status and the coil is continuously energized.</li> <li>If the closing or the trip is not performed properly, do not force the switchgear to do the operation, but remove the cause and then start the operation again. Otherwise, fire or malfunction may occur.</li> <li>Do not operate the switchgear while removing the ARC CHUTE. Otherwise, it may cause fire or failure of operation properties.</li> <li>Operate the switchgear in the automatic mode, not in the manual mode.</li> </ul>

### 4-1. Manual Operation

Our ATS guarantees the switching performance in the automatic mode. However, the switching performance, such as the switching power and the speed, varies according to the operator's capabilities. In the manual mode, we do not guarantee the switching performance as described in this manual.


 <b>WARNING</b>	<ul style="list-style-type: none"> <li>Make sure that all power supplies are blocked before starting manual operation.</li> <li>Otherwise, fire, electric shock, or a severe accident may occur.</li> </ul>
 <b>CAUTION</b>	<ul style="list-style-type: none"> <li>Performing load switching in the manual mode may cause contact consumption or contact fused. Do not perform manual operation except the cases described below.             <ol style="list-style-type: none"> <li>The switch performs switching continuously without the control power.</li> <li>Inspection of the control devices and the contact section is performed during idle operation.</li> <li>The switch does not operate due to any abnormalities of the switchgear.</li> </ol> </li> <li>When performing manual operation, make sure that the control power is turned 'OFF'. Otherwise, electric shock may occur.</li> </ul>

### 1. TYPE 'WN'

TYPE 'WN' allows operations of A→A, A→B, B→B, B→A, and neutral.

#### 1) Trip

The switchgear is tripped when a screwdriver is inserted into the T section while the manual handle is pulled out.





- Make sure that the manual handle is pulled out before trying trip. Otherwise, the worker may be injured. After the switchgear has been tripped, ensure that the 'ON' and 'OFF' display is changed to 'OFF'.


## 2) How to input power to the A side



Place the manual handle onto the (M) control shaft.



Turn the handle to the direction indicated by the arrow in the figure.



Check whether the ON/OFF display shows 'ON'.



After completing control, pull out the handle.




- Remove the manual handle after controlling the shaft. If the handle is not removed, the worker may be injured while the ATS is being operated.


## 3) How to input power to the B side




Place the manual handle onto the (M) control shaft.



Insert and push a screwdriver into the S section.



While the screwdriver is being pushed into the S section, control the manual handle in the direction indicated by the arrow.



Check whether the ON/OFF display shows 'ON'. After completing control, pull out the handle.



- Remove the manual handle after controlling the shaft. If the handle is not removed, the worker may be injured while the ATS is being operated.

## 2. TYPE 'W'

TYPE 'W' is switched as A→B and B→A.



- For manual operation, make sure that the control power is set to 'OFF'. If the handle is not removed, the worker may be injured while the ATS is being operated.




Place the manual handle onto the (M) control shaft.



Turn the handle to the direction indicated by the arrow in the figure until the handle stops.



When returning the handle to the original position, the contact is switched over.



Check whether the ON/OFF display shows 'ON' or 'OFF' according to the operation.



### CAUTION

- When input is made to the A side, the B side is tripped. In addition, when input is made to the B side, the A side is tripped.
- Remove the manual handle after controlling the shaft.

## 4-2. Automatic Operation

For automatic operation, please refer to the following operation circuit as a reference.




### CAUTION

- If the closing or the trip is not performed properly, do not force the switchgear to do the operation, but remove the cause and then start the operation again.
- Do not issue both the closing command and the trip command; when both the closing command and the trip command are issued to the same power simultaneously, the switch status is changed to the closing status and the coil is continuously energized.

### 1. WN TYPE

#### ① Control circuit




Name			
CC	Closing Coil	AX, BX	Control Switch
SI	Silicon Rectifier	SC	Selection Coil
LS	Limit Switch	TC	Trip Coil
ATS <sub>1</sub> , ATS <sub>2</sub>	Trip Control Switch	AUX	Auxiliary Switch


Operation Terminal	
A1-A2	Input Terminal at the Power A
B1-B2	Input Terminal at the Power B
AT1-AT2	Trip Terminal at the Power A
BT1-BT2	Trip Terminal at the Power B

## ② Example of the operation circuit


a) For general switchover (Instantaneous switchover)




b) For manual-automatic switchover COS section



c) For using the switchover timer




d) For condenser trip



## 2. W TYPE


1) 100~200A W-Type

① Control circuit



## 2) 400A W-Type

### ① Control circuit




Name	
CC	Closing Coil
Si	Silicon Rectifier
Xa1-Xa2	Control Switch
Xb1-Xb2	


Operation Terminal	
A1-A2	Input Terminal at the Power A
B1-B2	Input Terminal at the Power B
AUX	Auxiliary Switch

### ② Example of operation circuit (common for 100-400A)

a) For general switchover (Instantaneous switchover)




b) For manual-automatic switchover COS section




27, 84 : RELAY

### 4-3. Circuit Diagram (CTTS)


#### 1) Operation Flow Chart



#### 2) Operation circuit



### 3) Internal circuit



A1, A2	"A" Power source side(On)
AT1, AT2	"A" Power source side(Trip)
ATS1, ATS2	Switch, Position contacts
BTS1, BTS2	
AUX1, 2	Switch, Auxiliary
AX, BX	Switch, Control
B1, B2	"B" Power source side(On)
BT1, BT2	"B" Power source side(Trip)
C	Coil, Closing
COM	Common
CTTS	Closed transition transfer switch
E <sub>1</sub> , E <sub>2</sub> , E <sub>3</sub>	Standby power source conn.
NO	Normally open
NC	Normally closed
N <sub>1</sub> , N <sub>2</sub> , N <sub>3</sub>	Utility power source
S1A, S1B, S1C	Switch, Position sensing
S2A, S2B	
S3A, S3B, S3C	
TC	Coil, Trip
T <sub>1</sub> , T <sub>2</sub> , T <sub>3</sub>	Customer load conn.

All contacts of switch shown in :  
 Utility : Closed  
 Standby : Open

× : Closed ○ : Open


Utility side	Switch position	Utility closed	Neutral	Utility open
Aux. 1	①COM - ②NC	×	○	○
	①COM - ③NO	○	×	×

Utility side	Switch position	Standby open	Neutral	Standby closed
Aux. 2	④COM - ⑤NC	○	○	×
	④COM - ⑥NO	×	×	○






# 5. External Dimensions

## 5-1. W-Type

### 1) 61CT Front Connection




## 2) 64W FRONT/BACK




Type	A	B
2P	245	141
3P	296	192
4P	347	243

## 5-2. WN-Type






### 1) 61WN~62WN FRONT/BACK



## 2) 64WN FRONT/BACK








### 3) 66WN FRONT/BACK








Type	A	B
3P	340	224
4P	400	284

#### 4) 68WN FRONT/BACK








Type	A	B
3P	400	284
4P	480	364

## 5) 610WN FRONT/BACK



Type	A	B
3P	400	284
4P	480	364



## 6) 612WN FRONT/BACK



Type	A	B
3P	452.5	334
4P	535.5	417





## 8) 620WN BACK



Type	A	B
3P	527.5	409
4P	635.5	517


## 9) 625~630WN BACK




Type	A	B
3P	602.5	484
4P	735.5	617

## 5-3. CTTS-Type

### 1) 61CT Front connection




- ❶ Manual operation hole
- ❷ Switchover display
- ❸ Main circuit terminal on the Power B side
- ❹ Main circuit terminal on the load side
- ❺ Main circuit terminal on the Power A side
- ❻ Auxiliary switch
- ❼ Manual handle




Arc space dimensions (S1) is 30 mm for 220 V of the circuit voltage, 60 mm for 600 V of the circuit voltage.

Type	A	B
2P	210.8	199.8
3P	240.8	229.8
4P	270.8	259.8

### 2) 62CT Front connection




- ❶ Manual operation hole
- ❷ Switchover display
- ❸ Main circuit terminal on the Power B side
- ❹ Main circuit terminal on the load side
- ❺ Main circuit terminal on the Power A side
- ❻ Auxiliary switch
- ❼ Manual handle




Arc space dimensions (S1) is 30 mm for 220 V of the circuit voltage, 60 mm for 600 V of the circuit voltage.

Type	A	B
2P	240.8	229.8
3P	285.8	274.8
4P	330.8	319.8

### 3) 64CT Front connection




- ❶ Manual operation hole
- ❷ Switchover display
- ❸ Main circuit terminal on the Power B side
- ❹ Main circuit terminal on the load side
- ❺ Main circuit terminal on the Power A side
- ❻ Auxiliary switch
- ❼ Manual handle



Arc space dimensions (S1) is 30 mm for 220 V of the circuit voltage, 60 mm for 600 V of the circuit voltage.

Type	A	B
2P	292.5	278.5
3P	352.5	338.5
4P	412.5	398.5

#### 4) 66-616CT Front connection



- ❶ Operation circuit terminal
- ❷ Manual operation hole
- ❸ Auxiliary switch
- ❹ Main circuit terminal on the Power A side
- ❺ Main circuit terminal on the load side
- ❻ Main circuit terminal on the Power B side
- ❼ Switchover display
- ❽ Manual handle



#### Arc space dimensions

Main circuit voltage		S1	S2
200V		430mm	25mm
600V		450mm	90mm


  

Dimensions		600A	800A	1000A	1200A	1600A
A	3P	465	510	570		
	4P	530	590	670		
B	3P	435	480	540		
	4P	500	560	640		
C		545	607	644		
G		10	12	15		
I		95	103	112.5		
J		65	80	100		
L		70	90	109		
M		15	15	15		
N		71	79	109		
Q		44	79	66		
R		75	75	75		
S		55	55	55		


## 5) 66-616CT Back connection



600A



1000A



1600A


- ❶ Operation circuit terminal
- ❷ Manual operation hole
- ❸ Auxiliary switch
- ❹ Main circuit terminal on the Power A side
- ❺ Main circuit terminal on the load side
- ❻ Main circuit terminal on the Power B side
- ❼ Switchover display
- ❽ Manual handle

### Arc space dimensions

Main circuit voltage	S1	S2
200V	26	430
600V	90	450

Dimensions	600A	1000A	1600A	
A	3P	465	510	570
	4P	530	590	670
B	3P	435	480	540
	4P	500	560	640
G	117.5	116.5	116.5	
M	65	80	100	
N	95	103	112.5	
Q	35	80	80	
R	10	15	15	
S	15	15	15	

## 6) 620-630CT Back connection



- ❶ Operation circuit terminal
- ❷ Manual operation hole
- ❸ Auxiliary switch
- ❹ Main circuit terminal on the Power A side
- ❺ Main circuit terminal on the load side
- ❻ Main circuit terminal on the Power B side
- ❼ Switchover display
- ❽ Manual handle

### Arc space dimensions


Main circuit voltage	S1	S2
200V	50	560
600V	100	600

Dimensions	2000A	3000A	
A	3P	685	835
	4P	820	1020
B	3P	645	795
	4P	780	980
E	119	114	
F	132.5	130	
G	15	20	
H	15	20	
I	103	128	
J	135	185	
L	90	125	

## 6. Inspection and Repair


To maintain the adequate performance of the power switchover switch, follow the standards described below when performing inspection and repair.




**6-1.** Perform inspection every six months to prevent malfunction or maloperation caused by dust and oil drops.



**6-2.** Visual inspection should be made to detect damages or discoloration of the contacts.



**6-3.** Rust, oxidation or dust on the contact surface may lead to contact failure. To prevent this, perform switching at least once a year.



**6-4.** Ensure safety of workers while performing inspection and check the tightness of nuts and bolts.

### 6-5. Inspection Standard

Inspection Category	Inspection Cycle	
	General environment	Severe environment
Instantaneous inspection	Once Every six months	Once Once a month
Regular Inspection	Once Once a year	Once Every six months
Temporary inspection	Inspection if required	

### 6-6. Instantaneous inspection

Inspection Item	Inspection Item
Visual inspection	<ul style="list-style-type: none"> <li>Overheating and discolorization of the terminals</li> <li>Rust</li> <li>Dust and damages by pollution</li> <li>Odd smell</li> </ul>
	<ul style="list-style-type: none"> <li>Cracks, damage, deformation, and discolorization discolorization of the insulating materials</li> </ul>

# 7. Regular Inspection

Inspection Items	Inspection Point	Countermeasures and Description
Related to insulating materials	Attached insulating frame for contacts	<ul style="list-style-type: none"> <li>• Is there any crack or damage on the insulating materials?</li> <li>• Is there any dust or moisture attached to the surface?</li> <li>• Are all bolts on the contact section properly tightened?</li> <li>• Is there any arc welding on the insulating plate?</li> </ul>
	Arc extinguish chamber	<ul style="list-style-type: none"> <li>• Is the arc extinguish chamber damaged significantly?</li> <li>• Is the arc extinguish plate damaged significantly?</li> </ul>
	Insulation resistance	<ul style="list-style-type: none"> <li>• Between the same phases, between different phases, and phase to earth</li> <li>• Insulation resistance of the control circuit</li> </ul>
Related to live parts	Contact section	<ul style="list-style-type: none"> <li>• Damage of the auxiliary contact</li> <li>• Is the contact state adequate?</li> <li>• Is the main contact smooth?</li> <li>• Is there any sign of overheating or discolorization on the conductor contacts?</li> <li>• Are the bolts of the contacts tightened appropriately?</li> </ul>
Related to Control Part	Mechanism	<ul style="list-style-type: none"> <li>• Is the state of the rotating section and the lubricated surface good?</li> <li>• Is there any damage or rust on the rotating section and the lubricated surface?</li> <li>• Is there any damage or rust on the springs?</li> <li>• Are the nuts and bolts of the control mechanism tightened appropriately?</li> <li>• Is there any E-ring or split pin that has been omitted or damaged?</li> </ul>

# MEMO



# WARRANTY



**Model**

**Manufacturing No.**

Warranty Period		Year		
Date Purchased		Year	Month	Date
Customer	Company	Tel.		
	Address			
Store	Name			
	Store Name			
	Address	Tel.		

- This product has been manufactured through strict quality control and testing.
- If the product is defective due to any manufacturing defect, we will repair it at no cost within the warranty period.
- After the expiration of the warranty period, we will repair the product at actual cost.
- Please produce this warranty when requesting repair service.

**\* Service Details**

**• Free Service**

- 2 years from date of purchase  
(2.5 years from date of manufacture if purchase date can not be confirmed)

**• Paid Service**

- You must pay a certain amount of fee after the warranty period and in the following cases.
  - When the product is defective due to user negligence.
  - When the product has been repaired or remodeled by a person other than authorized service personnel.
  - When the product is defective or damaged due to natural disasters such as fire and flood.  
When the user is not able to produce this warranty.

**VITRO EM**



# VITZRO EM

I N S T R U C T I O N M A N U A L

## Automatic Transfer Switches

---

### Head office & factory

327, Byeolmang-ro, Danwon-gu, Ansan-si, Gyeonggi-do, Korea  
Tel. +82-31-489-2000 Fax. +82-31-492-2216

### Seoul office

VITZRO Bldg, 7, Neungdong-ro 25-gil, Gwangjin-gu, Seoul, Korea  
Tel. +82-2-2024-3100 Fax. +82-2-3436-1900

### Busan office

3-109, Industrial Goods Shopping Center, 37, Gwaegam-ro,  
Sasang-gu, Busan, Korea  
Tel. +82-51-319-2765 Fax. +82-51-319-2766

### Service Center

327, Byeolmang-ro, Danwon-gu, Ansan-si, Gyeonggi-do, Korea  
Tel. +82-31-489-2105 Fax. +82-31-489-2121

---

- ※ This Instruction Manual is available on VITZRO EM's website.
- ※ This Instruction Manual may be modified without prior notice in order to improve the performance of products.
- ※ In the event of any problems or inconveniences related to our products, please contact VITZRO EM.

[www.vitzroem.com](http://www.vitzroem.com)



## **VITZROEM Co., Ltd.**

### **Head office & factory**

327, Byeolmang-ro, Danwon-gu, Ansan-si, Gyeonggi-do, Korea  
Tel. +82-31-489-2000 Fax. +82-31-492-2216

### **Seoul office**

VITZRO Bldg, 7, Neungdong-ro 25-gil, Gwangjin-gu, Seoul, Korea  
Tel. +82-2-2024-3100 Fax. +82-2-3436-1900

### **Busan office**

3-109, Industrial Goods Shopping Center, 37, Gwaegam-ro,  
Sasang-gu, Busan, Korea  
Tel. +82-51-319-2765 Fax. +82-51-319-2766



**Service Center +82-1577-1820**

This Manual may be modified without prior notice in order to improve the performance of products. Please contact us for accurate information of any specified product.

VITZROEM Agency